
## **DISCO 4000**

# SERVICE MANUAL







## 1 Parts List

Ref. No.	Parts No.	Description		Q'ty	Ref. No.	Parts No.	Description	Q'ty
1 1 2 3 4 5 6 7	D 10054010 D 10054140 D 10070000 D 49179000 D 49178000 D 49170000 D 32107000 E 49199000	Cabinet Cabinet Panel front Knob, cueing/power Knob, quartz/speed Knob, start/stop Knob, pitch Spring	EUR AUS	1 1 1 2 2 1 1	55 55-1 55-2 55-3 55-4 55-5	C 49189000 C 32118000 D 49188000 D 32121000 F 49213000 D 46411010	Stylus illuminator Lamp Shade lamp Base lamp Cord assy (1P) Connector Jack	1 1 1 1 1
8 9 10	D 46403010 D 32110000 A 32109000	Connector plug Sheet, rubber Plate		1 1 1 1	56 57 57-1	42262079500 C 32112400 F 32113400	Printed circuit board, phono PC assy, power Printed circuit board	1 1
11 12 13 14 15 16 17 18 18 18 19 20	F 49172000 D 31753000 D 48521000 A 32108000 42312024000 D 20983000 K 47998000 K 48314000 131 22904134000 K 47869000	Sheet Hinge, cueing Hinge, power Angle mount SW, push 1 key (0) Pin, SW push Lid Plate, lid Plate, lid Pad, lid Hinge	EUR AUS	1 1 1 1 1 1 2 2	△ C401 △ R401 . 58 58-1 58-2 58-3 58-4 58-5 △ F101	42239709000 RH473102JZ0002 C 32112100 F 32113100 131 26201215000 42359230800 H 47577140 54631001400000 42342002500	CK 0.01µF 250V RH 1W 47K J  PC assy, control Printed circuit board Plate heat sink Fuse clip Label Tube Fuse 630 mA	1 1 1 2 1 1 1 1 1
21 22 23 24 25 26 27 28 29	A 20987020 F 49182000 131 26111148000 D 44421000 131 21801136000 131 25203244000 134 25205175000 D 49171000 D 31726000	Bottom plate Cord assy Bushing, phono Bushing, power Leg Felt Cushion Base, leg Filter		1 1 1 1 4 4 4 4	C101 C102 C103 C104 C105 C106 D101 D102 D103 $\triangle$ D104	CD1055000001V0 F 48913010 CD4762500001V0 CD1072500001V0 CD1062500001V0 CD4752500001V0 20252470135400 20253210200111 DGG W02	CD V 1MF 50V Elect 470MF 35V CD V 47MF 25V CD V 100MF 25V CD V 10MF 25V CD V 4.7MF 25V Diode DS135D Diode DS442 Diode GZA-20X Diode W02	1 1 1 1 1 1 1 1 1 1 1 1 1
30	D 31727000	Cover		1	IC101 IC102	20658584049100 F 49186000	IC LC4049B IC LC4027B	1 1
31 32 33 34 35 36 37 38 39 40	B 49173000 D 20994000 C 48506000 D 20988090 D 31752090 D 20451040 D 31338000 134 25205136000 B 48528000 B 48529000	Spacer Unit plate Arm rest assy Base pick up Base arm rest Turntable platter Support arm Cushion Spindle lifting Screw		3 1 1 1 1 1 1 1 1 1 1 1	Q101 Q102 R101 R102 R103 R104 R105 R106 R107 R108	20355000536500 20358570330400 RD104251JM0000 RD474251JM0000 RD471251JM0000 RD471251JM0000 RD104251JM0000 RD104251JM0000 RD103251JM0000 RD473251JM0000 RD473251JM0000	TR 2SC536E, F TR 2SD330D, E RD M 1/4W 100K J RD M 1/4W 470K J RD M 1/4W 470 J RD M 1/4W 100K J RD M 1/4W 100K J RD M 1/4W 47K J RD M 1/4W 47K J RD M 1/4W 47K J	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
41 42 43 44	E 48527000 D 48538000 D 48535090 134 22106124000	Spring Actuator Knob, IFC Holder		1 1 1 1	R110 R111 R112	RD152251JM0000 RD270251JM0000 RD103251JM0000	RD M 1/4W 1.5K J RD M 1/4W 27 J RD M 1/4W 10K J	1 1
45 46 47	134 24123208000 E 49209000 E 48540000	Arm Spring Rod		1 1 1	CN10P 59	F 49181000 C 32112200	Connector 10P assy PC assy, play	1 1
48 48-1 48-2 48-3 49 50 50	C 31910200 C 48700200 C 31910000 C 49207000 F 31827010 F 31324030 F 31324030	Tonearm assy Headshell assy Arm assy Weight assy Power switch Wire shield assy Wire shield assy	EUR AUS	1 2 1 1 1 1 1	59-1 59-2 59-3 D201 D202 R201 R202	F 32113200 42312058010 F 31706000 F 31834000 F 31834000 RD332251JM0000 RD332251JM0000	Printed circuit board Key board SW SW, push 1 key LED LN21RCPHL LED LN21RCPHL RD M 1/4W 3.3K J RD M 1/4W 3.3K J	1 1 1 1 1 1 1
⚠ 51 ⚠ 51 52 ⚠ 53 ⚠ 53	42432000710 F 47710010 F 32119000 F 32117400 F 32117600	Power cord Power cord DD Motor Power trans Power trans	EUR AUS EUR AUS	1 1 1 1	60 60-1 J2P VR501	C 32112500 F 32113500 131 29800010550 F 32116000	PC assy, volume Printed circuit board Jumper, 2P VR, 1K-B	1 1 1 1
54 54-1 ⚠ 54-2	141 01939040400 42262043600 46129706400	PC assy, neon Printed circuit board Neon lamp		1 1 1	61 61-1 61-2 D301 D302 R301 J3P	C 32112300 F 32113300 F 31706000 F 32115000 F 31834000 RD332251JM0000 131 29800010510	PC assy, speed Printed circuit board SW, push 1 key LED (G) LED LN21RCPHL RD M 1/4W 3.3K J Jumper, 3P	1 1 1 1 1 1 1 1
	·							


Ref. No	. Parts No.	Description Q'ty		Ref. No.	Parts No.	Description		Q'ty
62 62-1 J2P CN6 63 64 65 66 67 68 69 70 71 72 73	C 32112600 F 32113600 131 29800010550 F 32120000 A 48532000 C 49228000 134 25205120000 B 47284000 D 45269000 A 46556000 131 24201151020 D 49174000 F 46081000 D 43100000 134 26102157020	PC assy, remote Printed circuit board Jumper, 2P Jack  Angle mount Plate assy Cushion Nut (M12) Cramp wire Washer Screw Indicator  Cramp, speed PCB 45 rpm adapter Turntable platter mat	1 1 1 1 1 1 2 1 8 1 1 1 4		H 32122000 H 32122020 D 21082000 D 21083000 H 31766710 H 31766740 H 48494000 F 32124000 H 31538010 Cartridge fixing scri B 43212000 B 43212020 B 43212070 B 43213000 D 43214000	Carton box Carton box Pad, front Pad, rear Owner's manual Stylus position gauge Cord assy, remote Warranty card  ew set Screw 12L Screw 8L Screw 18L Nut M2.6 Washer	EUR AUS EUR AUS	1 1 1 1 1 2 2 2 2 2 2

No. Part No.	Part No. Description	Size	Q'ty
131 24201208000 132 131 24211950000 133 131 24211950100 144 131 24211950300 155 131 24211950300 166 131 24201190000 17 143 31903040110 188 143 31903008180 199 143 31903012180 0 131 24201199000 1 R 48014040 2 135 31903040110 3 101 313020003110 4 R 48563010 5 108 31102000030 6 105 31202000010 7 131 24220105020 8 141 24533368000 9 R 48554000 101 31 24203832050 11 102 32203006010	131 24211950000	M2.6 × 6 Ø3 × 8 Ø3 × 8 Ø3 × 10 Ø3 × 12 Ø3 × 25 Ø3 × 40 Ø3 × 8 Ø3 × 12 M3 × 6 Ø3 × 8 Ø3 × 40 M2 × 3 Ø4 × 55 Ø2 Ø2 Ø3 Ø3 Ø3 × 12 × 1 Ø3 × 12 × 1 Ø3 × 6	1 4 28 4 2 3 4 8 2 4 3 2 2 3 1 2 1 3 1 4 2 2 3 1 4 2 2 3 1 2 1 2 1 3 1 2 1 2 1 3 1 2 1 2 1






### 4 Schematic Diagram



#### **5** Controller Circuit Diagram



- 6 -